

CPx Application Instructions

Read these instructions COMPLETELY before you begin!

Trailer and pump make easy work of this process.



Spray product on gravel, then rake to till it into gravel / soil



After spraying first coat on gravel, rake product in and reveal dry spots



Dry spot shows up during first raking



CPx Application Instructions

Compaction is required to mix and tamp down material



Work in sections. Portion in front of picture has been completed and rolled



Hit the edges and joins with extra product



After product is tilled in and resprayed, it is ready to roll.



Remember to flush equipment with water right as you complete the job. Overspray can go on job or on nearby soil – will not harm soil.